








- The pump body protruding into the barrel needs to be cleaned occasionally.
- ▶ Place the Reversible Drum Vac in a mild cleaning or degreasing agent. After cleaning is complete, ensure that the float moves freely.





- ► Use a compressed air gun to remove solution residues and contaminants.
- ► The Soft Grip Safety Air Gun is ideal for this.
- ► (Don't forget wear eye protection.)





► If the Reversible Drum Vac becomes clogged, it can be disassembled for cleaning.





To remove the muffler, hold the hex body with a wrench while unscrewing the cylindrical muffler to the left using a strap wrench.









- After the silencer has been removed, mark the position between the tenon/bung and the main part so that the unit can be reassembled correctly after cleaning.
- ► Thanks to the pressed shim, the air gap should, if possible, have the original size ex works, which corresponds to a
- The volume flow meter was determined to be suitable.
- After dismantling the silencer unit, unscrew the threaded plug using a hook wrench.




► Carefully remove the spacer from the pump body and clean it with a mild cleaning or degreasing agent.





- ► Clean O-ring and threaded plug with a mild cleaning agent.
- Clean the inside of the pump body to remove residue from the spacer's contact surface.
- ► Use a compressed air gun to remove solution residues and contaminants. The Soft Grip Safety Air Gun is ideal for this.





- Allow all parts to dry before assembly.
- Note the position of the spacer shown below.
- ▶ Do not overtighten the threaded plug as this may damage the spacer and restrict airflow.

