




## **Air Cradle Safety Air Gun Mount INSTALLATION & MAINTENANCE**



**Model 5920 Air Cradle**

### **OVERVIEW**

The Air Cradle Safety Air Gun Mount is a simple and effective solution for keeping a safety air gun securely stored and easily accessible at any workstation. Designed for industrial environments, the Air Cradle uses a durable permanent magnet and an attachment ring to hold air guns, blowoff tools, and similar handheld equipment. By providing a dedicated storage location, it helps reduce clutter, prevent misplaced tools, and promote safer, more organized work practices.

This guide outlines the proper installation and use of the Air Cradle Safety Air Gun Mount. Following these instructions will ensure optimal performance and maintain a safe working environment. The information in this document is intended for operators, maintenance personnel, and supervisors responsible for workplace organization and safety compliance.

### **SAFE USAGE PRACTICES**

- Use only on clean, flat, ferromagnetic surfaces.
- Do not exceed the stated maximum load.
- Avoid impacts or sudden pulls that could dislodge the magnet.
- Inspect regularly and replace if damaged.

### **WARNINGS**

- Do not rely on the Air Cradle to secure loads that could cause injury or damage if dropped.
- Do not use the Air Cradle to support tools in critical or unstable positions, or in such a way that could put the workstation operator in danger.

### **MAXIMUM LOAD RATINGS**

Maximum Load Rating tested with Air Cradle installed on a clean, unpainted, 1-inch-thick steel surface.

**Maximum Load: 10 lbs**

If you have any questions or problems, please contact:

EPUTEC Drucklufttechnik GmbH  
Haidenbucherstr. 1 86916 Kaufering  
Phone: +49 8191 91 51 19 0  
Fax: +49 8191 91 51 19 91  
Email: [info@eputec.de](mailto:info@eputec.de)  
Website: [www.eputec.de](http://www.eputec.de)

